TOTO

使用说明书 Instructions for operation

使用产品前请仔细阅读本使用说明书,并保留备用。 Before using product, read these Instructions for operation carefully and retain it for future reference.

TOTO



明细单

目录

目	录·····	·1
明细	日 单······	2-4
使用]条件与使用上的注意······	5
使用]上的注意和保养······	6-7
产品	岀示意图····································	8-9
拆卸]与检查••••••	10
产品	└G 保修卡····································	11
合格	· 证········	12

明细单

散水板部······1套			
连接管部······1套			
装饰盖部······1套			
自攻螺钉·······3个 不锈钢垫片·····3个 合			
不锈钢垫片3个 合			
弯 头····································			
施工说明书······1本 合			
使用说明书······1本			

使用此明细单的产品包括:

DBX113-1CAM 固定花洒(淋浴·空气混入·脉动)

DBX113CAMR 固定花洒(淋浴·空气混入·脉动)

明细单

使用此明细单的产品包括:

DBX114-1CAM 固定花洒(淋浴·空气混入·脉动)

DBX114CAMR 固定花洒(淋浴·空气混入·脉动)

DBX115-1CAM 固定花洒(淋浴·空气混入·脉动)

DBX115CAMR 固定花洒(淋浴·空气混入·脉动)

DBX119-1CAM 固定花洒(淋浴·空气混入·脉动)

DBX119CAMR 固定花洒(淋浴·空气混入·脉动)

DBX120-1CAM 固定花洒(淋浴・空气混入・脉动)

DBX120-1CAM#PG 固定花洒(淋浴·空气混入·脉动)

DBX120CAMR 固定花洒(淋浴·空气混入·脉动)

DBX120CAMR#PG 固定花洒(淋浴·空气混入·脉动)

DBX121-1CAM 固定花洒(淋浴·空气混入·脉动)

DBX121-1CAM#PG 固定花洒(淋浴·空气混入·脉动)

明细单

使用此明细单的产品包括:

DBX121CAMR 固定花洒(淋浴·空气混入·脉动)

DBX121CAMR#PG 固定花洒(淋浴・空气混入・脉动)

DBX139CAM 固定花洒(淋浴·空气混入·脉动)

DBX139CAM#HN 固定花洒(淋浴·空气混入·脉动)

使用条件与使用上的注意

使 用 条 件

1. 供冷水*热水压力: 脉动混合空气水嘴

最低压力0. 05MPa

最高压力………0.5MPa

推荐使用压力……0.2~0.4MPa

- 2. 供水温度不得超过70℃,建议使用热水温度60±5℃,供热水请勿使用蒸汽。
- 3. 使用环境温度0℃以上。如果低于0℃,水嘴会出现变形、冻裂等现象。
- 4. 为防止花洒内部损坏,花洒侧吐水湿度不得超过60℃,建议使用温度45℃以下。
- 5. 长时间不使用时,可导致水嘴内部及外部锈蚀不能使用等现象。
- 6. 如果您需要废弃本产品,请勿将其作为一般生活垃圾处理,请依照法规经由独立的回收体系进行合适的处理、恢复和回收。
- 7. 本说明书中的产品具有清洗功能。

使 用 上 的 注 意

⚠ 警告 表示如果无视此标志而误操作时,有可能造成人员重伤或死亡。 ⚠ 注意 表示如果无视此标志而误操作时,有可能造成人身伤害或财产损失。

▲警告

- 1. 幼儿禁止使用或幼儿需要由成年人监护使用、老人和残障人士等特殊 群体应在有行动能力人员陪同下使用。
- 2. 水嘴的供热水一侧处于高温状态,请注意勿使皮肤直接接触五金配件表面,否则可能会烫伤。
- 3. 供热水请勿使用蒸汽,否则可能会烫伤。
- 4. 当直接从吐水口侧切换到淋浴侧或从淋浴器侧切换到吐水口侧时,水温会发生变化,要用手测试水温后再使用,否则可能会烫伤。
- 5. 如果客户不使用我司水嘴自带的进水口过滤网,可能会出现阀芯内因 异物进入而导致的漏水或破损的风险。

使用上的注意和保养

▲ 注意

- 1. 请勿撞击本产品, 否则可能会造成故障、漏水。
- 2. 必须使用中性洗涤剂清洗,中性以外的洗涤剂会破坏镀层或使表面变色。
- 3. 不得使用酸性洗涤剂和去污粉、抛光粉等含粗颗粒的洗涤剂和尼龙刷, 否则可能会破坏镀层等。
- 4. 可使用软布擦拭,间或用机油或车用蜡浸布擦拭,但请勿接触树脂部件, 否则可能失去光泽和产生锈蚀。
- 5. 建议不要长时间不使用,否则可能会导致水嘴内部以及外部锈蚀不能使 用等现象。
- 6. 随着产品式样的不断更新, 实物存在与图示不符的情况, 但基本安装、使用原理相同。
- 7. 花洒止水后,从花洒上有短时间滴水现象, 这是花洒头部的残留水排出,几分钟后还 没有停止的话,请确认手柄是否完全关闭。
- 8. 由于混入空气的原因,花洒头内部会有吸气声音,不是故障。
- 9. 水中含有的矿物质和盐分等污垢,堵塞花 洒橡胶喷嘴造成吸气口有水逆流出来,不 属于故障,请定期清理橡胶喷嘴。

10. 在可能结冰的场所使用时,要切实做好防冻措施。 因结冰,零件破损,有可能导致漏水,造成财产损失。因结冰而造成的 破损即使在保修期内也是有偿修理。请不要让产品的环境温度低于0°C。

防冻措施

在可能结冰的场所使用时,要切实做好防冻措施。

- 1. 产品结冰的话零件损坏,成为漏水的原因。
- 2. 因结冰造成的零件破损即使在保修期也是有偿修理。
- 3. 施工完了后或长时间不使用时,要有预防突然降温的准备,要对产品进行结冰预防。
- 4. 因为有结冰的危险, 请不要让产品周围的温度在0°C以下。


空气吸入口

使用上的注意和保养


▲ 保养

为长期保持产品的美观,请用户按以下方法维护保养。

- 1. 经常用软布擦拭,间或用软布蘸水擦拭。
- 2. 当有污垢且比较明显时,请用中性洗涤剂擦拭后充分进行水洗。
- 3. 散水板的保养与维护:
 - ●轻度脏的场合,将软布用温水浸湿 后拧干擦拭。
 - ●重度脏的场合,用软布蘸取适量中性洗涤剂擦拭后用清水充分清洗,再用软布擦干。
 - ●当喷嘴有堵塞、流线混乱时,将软布用温水浸湿后拧干擦拭,注意不要将喷嘴划破,如果太用力擦拭,喷嘴容易被划破、变形,从而造成流线变形。



产品示意图



产品示意图

DBX113-1CAM 固定淋浴头(淋浴·空气混入·脉动)

拆卸与检查

现象	检查项目
漏水	3, 4, 5, 6
松 动	1, 2, 3, 5, 7, 8
水流量小	4
进行拆卸)	F卸的情况下,请联络售后服务人员
脉动混空气系列水嘴	埋墙安装式系列脉动水嘴 自攻螺钉 (8. 是否充分拧紧?) 装饰盖 连接管
(1. 是否安装正确?)	固定圈 (7. 是否充分拧紧?)

(1. 是否安装正确?)

一(2. 是否充分拧紧?)

小螺钉 过滤网

(2. 是否充分拧紧?) (4. 有无划伤、脏物?) 固定套

连接球头

(5. 是否充分拧紧?) (3. 是否与连接 小螺钉

管充分拧紧?) 垫片 (6. 有无划伤?)

内部有节水器



△注意: 若出水不良,请用手揉搓几下吐水不良的小橡胶凸起。

产品保修卡

用户	
销售安装店	
购买日	
保修期	自购买日起主体及阀芯保修有效期5年, 其余部件保修期为1年

- * 若上栏内容未记全,该产品保修卡将视为无效。因此请用户购买时对记入内容进行确认。
- *本产品保修卡中的保修项目仅限于产品保修卡中所约束的免费维修项目进行维修。
- * 在保修期间, 若产品发生故障(漏水、渗漏), 请拨打全国售后服务电话报修。

维修规定

- 1. 保修期间,在用户正确按说明书、不干贴等指示,使用本公司产品的情况下,本公司将对有故障产品进行免费维修。
- 2. 在保修期内发生损坏需要得到免费维修时,请拨打全国售后服务电话报修。
- 3. 在保期内,下面所列场合的维修为有偿维修。
 - ①使用不当或私自进行的不当修理及改造所造成的故障及损伤。
 - ②安装施工时的不注意或过失造成的故障及损伤。
 - ③安装后又拆移等原因造成的故障及损伤。
 - ④超出使用范围以外的场合下使用本产品所造成的故障及损伤(如家庭用商品作为业务上商品使用。)
 - ⑤砂粒或污物等造成的损伤。
 - ⑥由于日常的维护保养不当造成的肮脏、电镀部分生锈等不良。
 - ⑦由于火灾、地震、水灾、雷击及其他天灾、公害、气害(液化气)、盐害及异常电压、使用指定外的电源(电压、频率)等原因造成的故障及损伤。
 - ⑧本产品保修卡没指定的场合。
 - ⑨本产品保修卡中用户姓名、销售店、安装店、购买日期未填写的场合。
 - ⑩不能出示购买发票的场合。
 - ⑪由结冰引起的故障。
- 4. 本产品保修卡只在中国境内有效。(香港、澳门、台湾地区除外)
- 5. 本产品保修卡丢失不补,请顾客妥善保管。

合格证

本品经检查判定合格

执行标准: GB/T 23447-2009、GB 28378-2019

产品型号: 见包装箱上的标签

产品名称: 见包装箱上的标签

生产日期:见包装箱上的标签

组装工厂: 东陶(大连)有限公司

电 话: (0411) 87624383

厂 址:大连经济技术开发区东北二街17号

东陶(中国)有限公司

全国售后服务申话: 800-820-9787(固定申话)

400-820-9787(手机用户)



扫描二维码, 服务预约,方便快捷

销售商: 东陶(中国)有限公司

地 址:北京市朝阳区光华路1号北京嘉里中心北楼1915室

网 址: www. toto. com. cn

Contents

Contents

Contents ·····	1
Detailed list	2-4
Service conditions and attentions in use	5
Attentions in use and maintenance	6-7
Product schematic diagram	8-9
Dismantle and inspection	10
Product Warranty Card	11
Conformity Certificate	12

Detailed list

	• 1		ı	• 4
Deta	П	$\Delta \alpha$	ı	ıct
DEIA	ш	IGU I	ı	ıσι

Pron plate part······ 1 set	
Connecting pipe part ······ 1 set	
Decorative cover part1 set	
Self-tapping screws3 Stainless steel gasket3 type series	
Stainless steel gasket3 type series	
Elbow	
Instructions for construction 1 copy	
Instructions for operation 1 copy	
The products using this detailed list include: DBX113-1CAM Fixed shower (shower·air mingling in·pulsation) DBX113CAMR Fixed shower (shower·air mingling in·pulsation)	

Detailed list

The products using this detailed list include: DBX114-1CAM Fixed shower (shower air mingling in pulsation) Fixed shower DBX114CAMR (shower air mingling in pulsation) DBX115-1CAM Fixed shower (shower air mingling in pulsation) DBX115CAMR Fixed shower (shower air mingling in pulsation) Fixed shower DBX119-1CAM (shower air mingling in pulsation) DBX119CAMR Fixed shower (shower air mingling in pulsation) DBX120-1CAM Fixed shower (shower air mingling in pulsation) DBX120-1CAM#PG Fixed shower (shower air mingling in pulsation) DBX120CAMR Fixed shower (shower air mingling in pulsation) DBX120-1CAM#PG Fixed shower (shower air mingling in pulsation) DBX121-1CAM Fixed shower (shower air mingling in pulsation) DBX121-1CAM#PG Fixed shower (shower air mingling in pulsation)

Detailed list

The products using this detailed list include:

DBX121CAMR Fixed shower

(shower air mingling in pulsation)

DBX121CAMR#PG Fixed shower

(shower air mingling in pulsation)

DBX139CAM Fixed shower

(shower air mingling in pulsation)

DBX139CAM#HN Fixed shower

(shower air mingling in pulsation)

Service conditions and attentions in use

Use condition

 Cold water supply*hot water supply pressure Impulse mixed air-water faucet:Minimum pressure 0.05MPa Maximum pressure...... 0.5MPa Recommended Operating pressure0.2-0.4MPa (flow pressure)

2. The hot water supply temperature must not exceed 70°C. It is suggested to use the hot water temperature of 60±5°C.Do not use steam to supply hot water.

3. The ambient temperature for use is above0°C. If the ambient temperature is lower than0°C, the faucet will deform and crack from freezing.

4. To prevent internal sprinkler damage, the water outlet temperature on the spinkler side shall not exceed 60°C, It is suggested to use a temperature below 45°C.

5. Being out of use for a long time may result in internal and external rust to the faucet and being unable to be used.

6. If you want to scrap this product, do not treat it as you do for general household garbage. Please follow relevant statutes to have it treated, recovered and collected appropriately by an independent recovery system.

7. The product in these instructions has a cleaning function.

Attentions in using

Warning: it means that ignoring this mark and misoperation may cause serious personal injury and death.

Attention: it means that ignoring this mark and misoperation may cause personal injury or property loss.

Warning

1. Children are not allowed to use or can use only under the custody of adult. Such special groups as the aged and disabled should be accompanied by those with behavioral competence when using it.

2. The hot water supply side of the faucet is in a condition of high temperature.

Do not allow skin to contact with the hardware surface directly. Otherwise,

scalding may occur.

 Do not use steam to supply hot water. Otherwise, scalding may occur.
 When switching directly from the water outlet side to the shower side or from the shower side to the water outlet side, the water temperature may change. Be sure to use after measuring the water temperature with hand. Otherwise, scalding may occur.

5. If a customer fails to use the self-contained water inlet filter net of our water faucet, there is such a risk as water leakage or damage due to foreign matters entering into the spool.

Attentions in use and maintenance

♠ Attentions

- 1. Do not impact the product. Otherwise, failure, water leakage may occur.
- 2. It is imperative to use a neutral detergent in cleaning. Other detergents than a neutral one may damage the plating coat or make the surface discolor.
- 3. Do not use any such detergent as acidic detergent and abstergent, polishing powder, etc. containing thick particles and nylon brush. Otherwise, the plating coat may be damaged, etc.
- 4. It is allowed to use a piece of soft cloth to wipe or use from time to time a piece of cloth immersed in machine oil or vehicle wax to wipe. However, do not contact with resin components. Otherwise, they may lose the gloss and become rusty.
- 5. It is suggested not to leave it unused for a long time. Otherwise, this may lead to internal and external rust to faucets to such a degree that it cannot be used any more etc.

6. With the product design being updated constantly, the physical object may not coincide with the figure. However, the basic principle for installation, use is the same.

7. Water will still drop within a short period after the shower stops sprinkling. It is the residual water in the shower head. If it does not stop in a few minutes, please check whether the handle is completely turned off.

8. There might be a suction-like sound inside the shower head due to inhaled air. It is not a fault.

9. The mineral substance salt an other dirt contained in water might block the rubber nozzle of the shower causing water back flow out of the air suction port.lt is not a fault. Please clean the rubber nozzle regularly.

10. When using in places where icing may occur, anti-freezing measures must be taken. The parts will be damaged due to icing, which may cause water leakage and property loss. Damages caused by icing are repaired for a fee even during the warranty period. Please ensure that the ambient temperature of the product is always above0°C.



Attentions in use and maintenance

Anti-freezing measures

When using in places where icing may occur, anti-freezing measures must be taken.

- 1. The parts will be damaged due to icing, which may cause water leakage.
- 2. Damaged parts caused by icing are repaired for a fee even during the warranty period.
- 3. After the construction is completed or when it is not used for a long time, prepare to prevent sudden drop of temperature and prevent the product from icing.
- 4. Because of the risk of icing, please ensure that the ambient temperature of the product is always above 0° C.

Maintenance

Rúbber

nozzle

To maintain a beautiful appearance of the product, the user is requested to conduct matntenance and care in the follouing method.

1. Wipe with a piece of soft cloth frequently and use a piece of soft cloth dipped in water to wipe from time to time.

2. When dirt exists obviously, please use water to wash sufficiently after wiping with a neutral detergent.

3. Maintenance and care of water spraying plate:

• In case of mild dirt, wipe it with soft cloth which is dipped into warm water and then wrung dry.


• In case of severe dirt, wipe it with soft cloth which is dipped into a proper quantity of neutral detergent, fully wash it with clean water and then wipe it dry with soft cloth.

• If the nozzle is blocked and the streamline is confused, wipe it with soft cloth which is dipped into warm water and then wrung dry.

Take care not to damage the nozzle. If the product is wiped with excessive force, the nozzle might be damaged or deformed, causing deformed streamline.




DBX113CAMR Fixed shower(shower - air mingling in - pulsation)






Product schematic diagram



Dismantle and inspection

Phenomenon	Inspecting items
Water leakage	3、4、5、6
Loose	1、2、3、5、7、8
The water flow is small	4

Once there is any failure after installation, remove according to the following main points. (In case of removing any of the spare parts and components not removed in this diagram, please contact with relevant service staff for removal) Impulse series water nozzle with air mixed



Product Warranty Card

User	
Sales shop or installation shop	
Buying date	
Warranty period	The warranty period for the body and valve core is 5 years and the warranty period for the remaining components is 1 year.

* If the contents in the above column are not recorded completely, the warranty will be deemed as invalid. Therefore, the users are requested to confirm the recorded contents when purchasing.

* The warranty items in this warranty are limited to repair to the free repair

items as restricted in it.

* During the warranty period, if the product breaks down (such as water leakage, oozing), please call after sale service to request repairs

Repair Regulations

1.In the circumstance that the users use correctly the product of our company according to the instructions on the instruction book, sticker, etc. during the warranty period, the company will provide free repair to any faulty product.

2. If damage occurs in the warranty period is required to be repaired for free, please call after sale service to request repairs.
3. The repairs listed below are paid repairs during the warranty period.

①Any failure and damage resulting from improper use or unauthorized improper repair and modification. 2 Any failure and damage due to failure to pay attention or mistake in

installation construction.

③ Any failure and damage due to removal for relocation, etc. after installation.

 Any failure and damage due to use of this product under such occasions as being beyond the range of use (for example, commodity for home use serves as commodity for business use).

5 Any damage resulting from sand or dirt, etc.

- 6 Any poor condition such as dirty, plating rust, etc. due to improper daily maintenance and care.
- (7) Any failure and damage due to fire, earthquake, flood, lightning strike and other act of God, public nuisance, gas nuisance (liquefied gas), salt nuisance and and abnormal voltage, use of other power sources than that designated (voltage, frequency) etc.

 8 Other occasions not indicated in this warranty.

9 The occasions where user name, sales shop, installation shop and purchase date are not filled out in this warranty.

1 The occasion where no purchase invoice can be shown.

(1) Failure caused by icing.

- 4. The warranty card is valid within the territory of the People's Republic of China. (Excluding Hongkong, Macao and Taiwan)
- 5. This warranty will not be reissued in case of loss. Customers are requested to preserve it properly

Conformity Certificate

This product is judged as satisfactory in inspection.

Applicable standard: GB/T 23447-2009 GB 28378-2019

Product Model No.: See the label on the packing box

Product name: See the label on the packing box

Production date: See the label on the packing box

Assembly factory:TOTO(Dalian)Co.,Ltd.

Telephone:(0411)87624383

Factory address: 17 Dong Bei Second Street, Economic & Technical Development

Zone.Dalian

TOTO(China)Co.,Ltd.

After-sale service toll free telephone all over the country:

800-820-9787(fixed telephone)

400-820-9787(for mobile phone users)



Service Reservation. Convenient and Efficient

Vendor:TOTO(China)Co.,Ltd.

Address: Room 1915, North Building of Beijing Jiali Center, No.1,

Guanghua Road, Chaoyang District, Beijing

Website:www.toto.com.cn